

Phocos CISCOM

PC Software for Phocos CIS Family Solar Charge Controllers

🏷 CISCOM 3.13		- 🗆 X
File Interface		phocos
Main menu		
Main Menu Main Menu Settings Datalogger and Status	Settings Prepare your CIS CU settings by following the steps: Please select your CIS Controller For CIS; CISN; CIS-LED; CIS-MPPT select: CIS/CIS-N Single Load Versions (with dimming CIS-MPPT, CIS-LED For CIS-2L; CIS-N-2L: CIS/CIS-N Dual Load Versions Read Settings from Controller:	g functions),
	Read Settings from Controller	
	Expert mode allows full customization of Load Timers, Low-Battery Behavior, and Battery Charge Regime:	Expert mode disabled
	Datalogger	
	Retrieve Data and Status Values from CIS-MPPT (CIS-MPPT Only):	
	Retrieve Data, Status and Settings from C	Controller
	Import System Data	
Communication	Import from File on Your Compute	r

Revision	Description
2013	Initial version
20200224	New version for CISCOM 3.13
20200507	Updated for CISCOM 3.14, preprogrammed LFP battery charge profiles added



Contents

1.0	Introc	luction	3
2.0	IMPO	RTANT SAFETY INFORMATION	3
3.0	Softw	are Installation and Getting Started	3
	3.1	Installation	3
	3.2	Getting Started with MXI-IR	4
	3.3	Getting Started with CIS-CU	5
	3.4	Getting Started without a Programming Accessory	6
4.0	Non-E	Expert Mode	7
	4.1	Nightlight Function	7
	4.2	SOC / LVD	11
	4.3	Night Detection Threshold	12
	4.4	Battery Type	12
	4.5	Print or Send	13
5.0	Exper	t Mode	13
	5.1	Enable or Disable Expert Mode	14
	5.2	Nightlight / Low Battery Settings	14
	5.3	Battery Charge Regime Settings	17
	5.4	Pre-programmed Battery Charge Regime Settings	18
	5.5	Saving Settings Files	19
6.0	Troub	leshooting and Workarounds	20
	6.1	Error Codes	20
	6.2	Workarounds	20
7.0	Liabili	ity Exclusion	20



1.0 Introduction

CISCOM software is a programming tool for CIS family solar charge controllers to adjust settings such as load control, battery charge profile, and low voltage disconnect. Additionally, CIS family MPPT controllers have datalogging, and data can be viewed through CISCOM.

CISCOM is intended for use with the MXI-IR programming accessory or to guide programming via CIS-CU remote control. Contact your Phocos sales representative for ordering information.

Features include:

- 2 modes, Non-Expert and Expert, offering easy to use preset profiles or full user customization
- Save settings files or datalogging files for sharing or troubleshooting
- Generate pictures of CIS-CU dials and switches from an easy to use graphical interface (Non-Expert mode only)
- Update firmware of CIS-MPPT-85/20 controllers
- Programmable 0..10V analog signal for compatible LED drivers with dimming
- Dimming settings triggered by time or low battery voltage
- Designed for Windows PC platform

2.0 IMPORTANT SAFETY INFORMATION

 \triangle

WARNING: Do not adjust settings in Expert Mode if you do not know the purpose or effect. Incorrect settings can damage batteries, cause excessive gassing, and create fire or explosion hazards.

CAUTION: Always follow the recommendations of your battery manufacturer.



IMPORTANT: Program all settings for a 12V battery. CIS charge controllers will automatically detect 12 or 24V batteries and automatically adjust settings for 24V systems.

3.0 Software Installation and Getting Started

3.1 Installation

Follow these 3 steps to install CISCOM.

- 1) **Download** the latest version of CISCOM from www.phocos.com \rightarrow Software Downloads.
- 2) **Extract** the files from the zip folder.

Right click on the zip file, and select "Extract All" from the menu.



↓ ○ 1 ▼	Extract	ownloads			-		×
Pile Home Share View	path shortcut development by to	Rename New folde	Propertie	Gopen •	Seli	ect all ect none ert selection Select	^
$\leftarrow \rightarrow \cdot \uparrow \clubsuit$ This PC >	OS (C:) > Users > Phocos >	Downloads			νÐ	Search Do.	. p
Name	Date modifi	ed	Туре	Size			
V Today (1)							
CISCOM_0313.zip > Last month (11)	Open Open in new window		Compressed (z	zippe	955	KB	
> Earlier this year (27) > A long time ago (23)	Extract All Pin to Start Scan with Webroot Edit with Notepad++ Provide Share Open with	>					
	Give access to Restore previous version	s >					
	Send to	>					
62 items 1 item selected 954 K	Cut Copy					100	

3) **Run** the executable file, and follow the prompts in the dialogue boxes.

3.2 Getting Started with MXI-IR

Follow these 5 steps to start using your MXI-IR with CISCOM.

- 1) **Connect** MXI-IR USB to computer.
- 2) **Connect** your charge controller to battery power.
- 3) **Clear** a line of sight between the IR transceivers of the MXI-IR and charge controller, and ensure the distance is less than 8 m (25 ft).



4) Select the COM Port using the Interface Menu.



S CI	5COM 3.13	
File Ma	Interface Refresh COM PORTS COM3 In menu	
• Se	Main Menu ttings Datalogger and Status	Settings Prepare your CIS Please select your CIS (For CIS; CISN; CIS-LEE CIS/CIS-N S

NOTE: If you see more than one COM option, check for the correct COM Port number using Windows Device Manager, or guess and test. Your COM Port number may be different than the picture. If no COM Port is available or if none of the options work, see the Troubleshooting Section, and follow the instructions for error code 1.

5) **Start** using CISCOM.

Read settings, retrieve data, or transmit settings using CISCOM menus and buttons.

3.3 Getting Started with CIS-CU

Follow these 5 steps to start using CISCOM to guide your programming with CIS-CU.

• Start using CISCOM in Non-Expert mode.

Use CISCOM menus and buttons to select settings and to generate a picture of CIS-CU dials and switches. Optionally, use the print feature to print the CIS-CU picture for later use.

SCISCOM 3.13		- 🗆 X
CISCOM 3.13 2 CISCOM 3.13 2 CISCOM 5.13 2 CISCOM	Printer Printer preview window Print	Document does not contain any pages.
Image: Section of the section of t	Additional information for the printout System Controller Comments Back	

- **Connect** your charge controller to battery power.
- Clear a line of sight between the IR transceivers of the CIS-CU and charge controller, and ensure the distance is less than 8 m (25 ft).



- Adjust your CIS-CU dials and switches according to CISCOM picture.
- **Press "Send"** button of CIS-CU to transmit settings.

3.4 Getting Started without a Programming Accessory

Follow these 2 steps to import a settings file (.cis) or to view a datalogger file (.cisdl).

- 1) Start CISCOM.
- 2) Import a cis or cisdl file by selecting "Import from File on Your Computer" button in the Main Menu.

SCISCOM 3.13	
Settings O Datalogger and Status	Settings Bronze your CIS CII settings by following the steps:
	Please select your CIS Controller
	For CIS: CISN: CISJ ED: CIS_MPPT select
	CIS/CIS-N Single Load Versions (with dimming functions), CIS-MPPT, CIS-LED
	For CIS-2L; CIS-N-2L:
	CIS/CIS-N Dual Load Versions
	Read Settings from Controller:
	Read Settings from Controller
	Expert mode allows full customization of Load Timers, Low-Battery Behavior, and Battery Charge Regime:
	Datalogger
	Retrieve Data and Status Values from CIS-MPPT (CIS-MPPT Only):
	Retrieve Data, Status and Settings from Controller
	Import System Data
	Import from File on Your Computer
Communication	

Follow these 3 steps to program and save a settings file (.cis).

- 1) Start CISCOM.
- 2) **Program** a settings file in Non-Expert Mode by selecting "CIS/CIS-N Single Load Versions (with dimming functions), CIS-MPPT, CIS-LED" button in the Main Menu. For Expert Mode, see Section 5.0.



🏷 CISCOM 3.13		- 🗆 X
File Interface		phocos
Main menu		
Main Menu Settings Datalogger and Status	Settings Prepare your CIS CU settings by following the steps: Please select your CIS Controller For CIS CONTROL AND SET STATES	:
	CIS/CIS-N Single Load Versions (with dimmi CIS-MPPT, CIS-LED	ing functions),
	For CIS-2L; CIS-N-2L:	
	CIS/CIS-N Dual Load Versions	5
	Read Settings from Controller:	
	Read Settings from Controlle	r
	Expert mode allows full customization of Load Timers, Low-Battery Behavior, and Battery Charge Regime:	Expert mode disabled
	Datalogger	
	Retrieve Data and Status Values from CIS-MPPT (CIS-MPPT Only):	
	Retrieve Data, Status and Settings from	n Controller
	Import System Data	

If you have a dual load controller (discontinued), then choose "CIS/CIS-N Dual Load Versions" button instead. These products can be identified by the 2 load wires and no thin black dimming wire.

4.0 Non-Expert Mode

Non-Expert Mode is appropriate for users who have lead acid batteries who may also want to use load programming and adjust low voltage disconnect (LVD) settings or dimming settings.

4.1 Nightlight Function

The Nightlight Function menu is used to program load on/off and dimming on/off controls based on time and reference points like dusk, dawn, or the middle of the night. Use the graphical aid to see the effect of settings changes.

Remember, CIS family controllers intelligently detect day and night based on solar PV voltage. If timer settings exceed the length of night at the install location, the daytime solar PV voltage will still cause the load to turn off.



NOTE: The slider bar for length of night does not control anything. Use the slider bar to see how nightlight settings will automatically adapt to seasonal changes in night length.

There are 3 settings modes available:

- Standard Controller: Load is on all the time
- Dusk to Dawn: Load turns on at dusk and off at dawn
- Evening/Morning: Load turns on at dusk and off at dawn with an off period in between

Rather than turning the light off, you can choose dimming instead, or choose a combination of dimming and off hours. These features save battery energy to avoid low voltage disconnect events caused by bad weather or aging batteries.



Dimming is only available for CIS family controllers that have built-in LED drivers, or when a CIS family controller dimming wire is connected to a compatible LED driver. For CIS controllers with built-in LED drivers, dimming is accomplished by pulse width modulation (PWM).



SCISCOM 3.13		-		\times
Main Menu	Light ON			^
O Settings O Datalogger and Status	Turn light ON from Dusk to Dawn (Entire Night)			
1. Select CIS controller	based on dusk and dawn			
2. Nightlight Function	Turn light ON at dusk. Turn light OFF			
4. Night Detection Threshold	Turn light ON 0 v hour(s) before Dawn. Turn light OFF at Dawn.			
 5. Battery Type 6. Print 	Dimming			
	based on dusk and dawn			
Error OK Transmit	Full brightness at Dusk. Dim light 1 💛 hour(s) after Dusk.			
0 0 0	Full brightness 0 v hour(s) before Dawn.			
Test	Brinhtnass whan Dimmins Active 50 x 94			
11 9 7 11 9 7 Send				
Evening (h) Evening (h)	Light ON			
D2D 1 D2D 1 Timer 13 3 13 3 Reference	Dimmins			
5 11.0 h based on	Light ON / dimming / OFF 🖞 🍟 🍟 🍟 🍟 🍟 🍟 🍟 🍟 🍟 🍟 🍟			
3-0-11.4 3-0-11.4 3-0-11.4 3-0-11.4	Light 100% ON			
SOC LVD.(V) SOC LVD.(V) Duck & Deven	Brightness 50%			
10 ²⁵ 3 0 10 A 97774 07-30 0				
8 5 5 100 5 50 B B	Middle of Night			
Night Detect (V) Dimming (%)	SHE SHE			
Import Settings from Controller	Dusk Dawn			
Send Settings	and the second			
	Length of Night 12 hours			
	Back		Next	

Figure 4.1: Nightlight Settings Menu, Non-Expert Mode, Standard Controller Settings

For Dusk to Dawn (D2D) mode, check the box for "Turn light ON from Dusk to Dawn (Entire Night)".



For Evening/Morning mode, check one or both boxes for "Turn light ON at dusk. Turn light OFF ____ hour(s)

[reference]" or "Turn light ON ____ hour(s) [reference]. Turn light OFF at Dawn." Next, select your preferred time reference with the drop-down menu, either "based on dusk and dawn" or "based middle of the night". Next, select your preference of hours using the drop-down menus. Use the graphic and slider bar to see how the settings would be implemented.



Turn light ON from Dusk t	o Dawn (Entire Night)		
base	d on dusk and dawn v rn Tight OFF 2 v hour(s) before Dawn. Tr	hour(s) after Dusk. um light OFF at Dawn.	
Dimming			
Eul brightness at Dusk	d middle of the night v	hour(s) before Middle of the Ne	ght.
Brightness when Dimmi	ig Active 50 ~ %	er regen.	
Light ON Dimming Light ON / dimming / OFF Light 100% ON Brightness 50% Light OFF – Day / Night	28 V V V Dusk Length 1	8h Widdle of Night Middle of Night Daw	×× m Next
Figure 4.3: Ev	enina/Mornina	Example with Dus	k and Dawn Reference

In the above example, there will be no off time when the length of night is 10h or less.



Figure 4.4: Evening/Morning Example with Middle of the Night Reference

In the above example, the load will not turn on if the length of night is 6h or less.



Light ON	
Turn light ON from Dusk to Dawn (Entire Night)	Middle of Night
Turn light ON at Dusk. Turn light OFF 2 v hour(s) before Middle of the Night	┝╲ _{┥┝} ┎┥│
Turn light ON 0 v hour(s) after Middle of the Night. Turn light OFF at Dawn.	
Dimming	
based on dusk and dawn	Wideling of Nicht
Full brightness at Dusk. Dim light 2 v hour(s) after Dusk.	
🗹 Full brightness 3 🗸 hour(s) before Dawn.	┛╶┤┿┶╻╽┎┵╃┧╴║
Brightness when Dimming Active 50 × %	
Dimming Light ON / dimming / OFF Light 100% ON Brightness 50% Light OFF Day / Night Kiddle of Night	<mark>* *</mark>
Length of Night 14 hours	

Figure 4.5: Evening/Morning Example with Different Reference Points for Load ON/OFF and Dimming ON/OFF

In the above example, if the length of night decreases, dimming time will decrease.

To adjust the dimming level, use the drop-down menu. At 100%, lights will be at full brightness when dimming is enabled. At 0%, lights will be off when dimming is enabled. There is a linear correspondence in between.

based Turn light ON at Dusk, Turr	iddle of the night	Middle of Night
Turn light ON 3	hour(s) after Middle of the Night. Turn light OFF at Daw	Night.
Dimming based	iddle of the night v light 15 v hour(s) before Middle of the hour(s) after Middle of the Night. .ctive 80 v %	Night.
Light ON 15h Dimming Light ON / dimming / OFF Light 10% ON Brightness 80% Light OFF Day / Night	Image: Second	Itan Xawa

Figure 4.6: Dusk to Dawn with Dimming All Night



4.2 SOC/LVD

Low voltage disconnect (LVD) protects lead acid batteries from damage by preventing over discharge. Over discharge can lead to shortened battery lifespan.

Low voltage dimming extends run time of lights when the batteries are not fully charged due to bad weather or when batteries are aging and cannot hold a charge.

There are 2 modes of LVD and low voltage dimming:

- Voltage controlled
- State of Charge (SOC) controlled

Voltage controlled LVD considers battery voltage only. When the controller measures a battery voltage below the setting for a few minutes, it will disconnect (or dim) the load.

SOC controlled LVD considers battery voltage and load current. When load current is high, the controller will wait for a lower battery voltage before disconnecting (or dimming), and it will wait longer before disconnecting (or dimming). SOC settings are valuable because battery voltage alone is not a complete indicator of battery state of charge.

Battery voltage must be below the setting for longer than 2 minutes and up to 30 minutes for LVD or low voltage dimming to take effect. Low voltage dimming settings must be higher than LVD settings to take effect.



IMPORTANT: Program all settings for a 12V battery. CIS charge controllers will automatically detect 12 or 24V batteries and automatically adjust settings for 24V systems.

To determine when SOC settings will apply, you will need to know the load current consumption and the controller's load current rating. For example, CIS-N-MPPT-85/20 is rated for 20A. If a connected streetlight was consuming 14A, that would be 70%, or 0.7, of the controller's nominal current capacity. If SOC4 was selected, the graph below shows the battery voltage must drop below 11.55V for the controller to implement LVD. There is also a time delay.



Figure 4.7: SOC4 Setting for LVD



4.3 Night Detection Threshold

As dusk turns to night, solar voltage drops to a very low level. As night turns into dawn, solar voltage increases from a low level up to levels that can be used for battery charging. CIS family charge controllers intelligently detect this change of state by utilizing the Night Detection Threshold setting.

Night Detection Threshold is only relevant for Dusk to Dawn or Evening/Morning load settings. Night Detection Threshold is the PV array open circuit voltage at which the controller will determine the night state. Night Detection Threshold + 1.5V is the level at which the controller will determine the day state.

Increasing the voltage means the load will turn on sooner at dusk and turn off later at dawn. Decreasing the voltage means the load will turn on later at dusk and turn off sooner at dawn. If this setting is too low and there is ambient light, then the controller might not be able to transition to night properly.

Night detection 8.0 Night detection level (default value is 8 V) 10.0 95 If the PV panel voltage the "Night Detection Level", the controller starts the nightlight program within two minutes 9.0 8.5 Day detection level 9 7.5 If the PV panel voltage e the "Day Detection Level", the controller stops the nightlight program within two minutes 7.0 6.5 Recommendation: 6.0 In most cases, the defi at the location before of f 8V works properly. For accurate settings, measure the PV panel voltage at night 5.5 night detection level. 5.0 4.5 4.0 3.5 3.0 2.5 **PV** Voltage 9.5 V 8.0 V

To change this setting, mark the checkbox and use the dropdown.

Figure 4.8: Night Detection Threshold Menu

Time

4.4 Battery Type

The "Lead acid battery" setting enables equalization charging. This is intended for flooded or liquid electrolyte lead acid batteries. The "Sealed battery" setting disables equalization charging.



CAUTION: Always follow the charging recommendations of your battery manufacturer.



Batt	ery type
1	Standard default settings
0	Lead acid battery
	Includes float, boost and equalization mode
•	Sealed battery
	All other lead acid battery types (VLRA, AGM, GEL, sealed)
	Includes float and boost mode

Figure 4.9: Battery Type Options to Enable or Disable Equalization Charging

4.5 Print or Send

Use the "Printer preview window" or "Print" buttons to trigger the Windows printer dialogue box and print a picture of the CIS-CU settings. Or, use the "Send Settings" button to transmit settings to a CIS family controller via the MXI-IR accessory.

Main Menu O Settings Datalogger and Status 1. Select CIS controller 2. Nightlight Function	Printer Printer preview window	^
 3. SOC / LVD 4. Night Detection Threshold 5. Battery Type 6. Print 	Print	
Error OK Transmit		Document does not contain any pages.
20 ⁰ F 1 13→2→3 13→	Additional information for the printout	د >
0,2,5,3 0,10 0,	System Controller Comments	

Figure 4.10: Print CIS-CU Picture or Send Settings Via MXI-IR

5.0 Expert Mode

Expert Mode is appropriate for users who:

- have lithium ion batteries
- need access to additional low voltage disconnect options (LVD)
- have CIS-N-MPPT-LED or CIS-N-LED and need to program the LED current
- need to save settings files for later use
- have experience with solar design, batteries and CIS family charge controllers





WARNING: Do not adjust settings in Expert Mode if you do not know the purpose or effect. Incorrect settings can damage batteries, cause excessive gassing, and create fire or explosion hazards.

CAUTION: Always follow the recommendations of your battery manufacturer.

IMPORTANT: Program all settings for a 12V battery. CIS charge controllers will automatically detect 12 or 24V batteries and automatically adjust settings for 24V systems.

5.1 Enable or Disable Expert Mode

To enable Expert Mode, select the "Expert Mode Disabled" status button from the main menu. To disable Expert Mode, select the "Expert Mode Enabled" status button from the main menu.

S CISCOM 3.13	- a ×
File Interface	phocos
Settings Datalogger and Status	Settings Prepare your CIS CU settings by following the steps: Please select your CIS Controller
	CIS/CISN; CISN; CIS-MPPT select: CIS/CIS-N Single Load Versions (with dimming functions), CIS-MPPT, CIS-LED
	For CIS-2L; CIS-N-2L:
	CIS/CIS-N Dual Load Versions
	Read Settings from Controller:
	Read Settings from Controller
	Expert mode allows full customization of Load Timers, Low-Battery Behavior, and Battery Charge Regime: Expert Mode Disabled

Figure 5.1: Non-Expert Mode

S CISCOM 3.13	X
File Interface	phocos
Main Menu	
Settings Databager and Status	Settings Settings Read Settings from Controller:
	Read Settings from Controller
	Expert mode allows full customization of Load Timers, Low-Battery Behavior, and Battery Charge Regime: Expert Mode Enabled

Figure 5.2: Expert Mode

5.2 Nightlight / Low Battery Settings

Load 1 is the load output for single load controllers such as CIS-N and CIS-N-MPPT. Load 2 is the dimming



control signal for single load controllers.



NOTE: Load disconnect events will override the load programming timers. Day and night detection will override any load programming timers for D2D or Morning and Evening.

IMPORTANT: Program all settings for a 12V battery. CIS charge controllers will automatically detect 12 or 24V batteries and automatically adjust settings for 24V systems.

Nightlight / Low Battery Settings	Description
	No Nightlight will turn the load output on all the time. (Standard Controller)
	D2D will turn the load output on at dusk and off at dawn.
Nightlight Mode (Load 1)	Morning and Evening hours based on Dusk & Dawn will use dusk and dawn as reference points for hourly settings with evening hours after dusk and morning hours before dawn.
	Morning and Evening hours based on Middle of the night will use the midpoint between dusk and dawn as a reference point for hourly settings with evening hours before the middle of the night and morning hours after the middle of the night.
	With Morning and Evening hours based on Dusk & Dawn, this is the number of hours the load will be on after dusk.
ON Hours After Dusk (Load 1)	With Morning and Evening hours based on Middle of the night, this will be the number of hours before the middle of the night when the load will turn off.
	With Morning and Evening hours based on Dusk & Dawn, this is the number of hours the load will be on before dawn.
ON Hours Before Dawn (Load 1)	With Morning and Evening hours based on Middle of the night, this will be the number of hours after the middle of the night when the load will turn on.
LVD Indicator Type (Load 1)	SOC is a battery state of charge controlled low voltage disconnect.
	Voltage is a battery voltage controlled low voltage disconnect.
	With SOC LVD, higher numbers disconnect the battery at a higher SOC. Lower numbers disconnect the battery at a lower SOC.
LVD load 1 Offset	With Voltage only LVD, the setting will be the battery voltage offset added to the base voltage. The sum of these voltages will be the battery voltage level that triggers LVD.
LVD: Base + Offset (V)	This is the automatic calculation of the sum of the base voltage and offset voltage used to trigger LVD.
Nightlight Mode (Load 2)	No Nightlight will keep dimming off except by LVD.



	D2D for Load 2 is not applicable to dimming features at night. Setting No Nightlight for Load 1 and D2D for Load 2 will dim the light during the day and switch to full brightness at night.
	Morning and Evening hours based on Dusk & Dawn will use dusk and dawn as reference points for hourly settings with evening hours after dusk and morning hours before dawn. Evening hours are the delay after dusk until dimming is implemented. Morning hours are when dimming will end before dawn, and the light will switch to full brightness.
	Morning and Evening hours based on Middle of the night will use the midpoint between dusk and dawn as a reference point for hourly settings with evening hours before the middle of the night and morning hours after the middle of the night. Evening hours are the number of hours before middle of the night when dimming will start. Morning hours are the number of hours after middle of the night when dimming will end.
	The load must be on for dimming to take effect.
	With Morning and Evening hours based on Dusk & Dawn, this is the delay when dimming will take effect after dusk.
ON Hours After Dusk (Load 2)	With Morning and Evening hours based on Middle of the night, this will be the number of hours before the middle of the night when dimming will take effect.
	The load must be on for dimming to take effect.
	With Morning and Evening hours based on Dusk & Dawn, this is the number of hours before dawn when dimming will stop.
ON Hours Before Dawn (Load 2)	With Morning and Evening hours based on Middle of the night, this is the number of hours after the middle of the night when dimming will stop, and the light will switch to full brightness.
	The load must be on for dimming to take effect.
LVD Indicator Turne (Lood 2)	SOC is a battery state of charge controlled low voltage dimming.
LVD indicator Type (Load 2)	Voltage is a battery voltage controlled low voltage dimming.
	With SOC low voltage dimming, higher numbers implement dimming at a higher SOC. Lower numbers implement dimming at a lower SOC.
LVD load 2 Offset	With Voltage only low voltage dimming, the setting will be the battery voltage offset added to the base voltage. The sum of these voltages will be the battery voltage level that triggers low voltage dimming.
	The load must be on for dimming to take effect.
LVD: Base + Offset (V)	Automatic calculation of the sum of the base voltage and offset voltage used to trigger low voltage dimming. This must be higher than the value for Load 1 for dimming to take effect.
Day/Night Threshold	PV array voltage at which the controller will switch from day to night mode. The controller will switch from night to day at 1.5 /



	3.0V above this level.
	Gel disables Equalize Charging.
Battery Type	Flooded enables Equalize Charging.
	For CIS controllers with a dimming wire, 100% corresponds to a 10V signal, and 0% corresponds to a 0V signal on the dimming wire. There is a linear correspondence in between.
Dimming percentage	For CIS controllers with integrated LED drivers, 100% corresponds to full brightness, and 0% corresponds to off. There is a linear correspondence in between.
	Dimming is accomplished by PWM.
	For CIS-N-MPPT-LED:
	This setting reduces LED output current linearly and is a percentage of the maximum 3500mA output. 100% corresponds to 3500mA, and 0% corresponds to 0mA with a linear correspondence in between.
	Linear LED output current before dimming = 3500mA * (Dimming Base Level Value %)
Dimming Base Level Value	For example, if the desired LED current before dimming is 2500mA, then select 70.0. (2500mA/3500mA)*100 = 71.4%
	70.0% is the closest allowable value below 71.4%.
	Any Load 2 settings for dimming will apply the dimming percentage to the adjusted value, but dimming will be accomplished by PWM.
	For CIS-N-LED:
	This setting reduces LED output current by PWM and is a percentage of the nominal rated value. Any Load 2 settings for dimming will additionally apply the dimming percentage, and dimming will be accomplished by PWM.

5.3 Battery Charge Regime Settings

Battery Charge Regime Setting	Description	
Emergency High Voltage	Fast acting protection intended primarily for a wiring error, when a fuse blows, or to stop charging when a secondary source (i.e. generator) is unregulated or in error.	
Maximum Charge Voltage	Highest charge voltage allowed by temperature compensation. (Higher values can often be seen in the datalogger due to quick fluctuations from high C-rates.)	
Equalize Voltage	Equalize voltage at 25°C. Only active when the Battery Type setting is selected as Liquid. It's	



	disabled when Gel is selected. This stage is chosen if the battery was discharged <12.1/24.2V the night before. Overrides Main and Boost charge.
Boost Voltage	Boost (Absorption) voltage target at 25°C. Setting applies to both the 2hr Boost charge and the 30min Main charge. The 2hr is chosen if the battery was discharged <12.3/24.6V the night before. Overrides the 30min Main charge.
Minimum Boost Voltage	Lowest Boost (Absorption) or Equalize charge voltage allowed by temperature compensation.
Float Voltage	Float voltage at 25°C.
Minimum Charge Voltage	Lowest Float charge voltage allowed by temperature compensation.
Load Reconnect Voltage	After dimming due to low voltage or LVD has occurred, they will continue until the battery bank is charged above this level.
Emergency Low Voltage	Fast acting protection intended primarily for a wiring error or old batteries. Similar to LVD, but immediate.
Base Voltage LVD	Reference voltage for adjusting voltage controlled LVD settings. An offset is added to this voltage to create the final LVD or dimming voltage settings.
Base Voltage SOC	Reference voltage for adjusting SOC controlled LVD settings. This reference voltage will be the battery voltage when no load current is flowing.
Maximum step for SOC	A step for how the SOC LVD setting will compensate for load current.
Temperature Compensation	Units of millivolts. The "negative" is already in the internal calculation. It's the total for a 12V battery (6 cells). In cold weather, the target charge voltage will be increased by this amount for every degree below 25°C. In hot weather, the target charge voltage will be decreased by this amount for every degree above 25°C. Referencing K instead of °C helps avoid confusion with negative signs when the ambient temp is <0°C.

5.4 Pre-programmed Battery Charge Regime Settings

Expert mode includes three buttons for preprogrammed battery charge setting profiles:

- "Lead acid"
- "LFP full capacity"
- "LFP extended life"

Battery Charge Regime Settings will automatically change in the software. Battery Type must be updated manually if required.

When Battery Type is Gel, the "Lead Acid" profile is best suited for AGM, gel, or other sealed type lead acid batteries. When Battery Type is Liquid, the Lead Acid profile is best suited for flooded or wet cell type lead acid batteries that need the Equalize charge stage enabled.

"LFP full capacity" is for lithium iron phosphate batteries with a BMS where charging to 100% capacity is a priority with a tradeoff in lifespan.

"LFP extended life" is for lithium iron phosphate batteries with a BMS where extended lifespan is a priority with a small tradeoff in capacity.



Sec.	1	0.00	0.11	1.00	10.1
500	10.1	1842.			122
20	-	~~~			1.11

photo Inightlight / Low Battery Settings Settings Nightlight / Low Battery Settings Settings / Datalogger and Statur Nightlight / Low Battery Settings 0 0 0 Nightlight / Low Battery Settings 0 0 0 0 0 Nightlight / Low Battery Settings 0	LISCOW 3.14			
Nightlight / Low Battery Settings Settings Datalogger and Status Nightlight Mode 0 ON Hours After Dusk (Load 1): 0 ON Hours After Dusk (Load 1): 0 Viphtlight / Low Battery Settings Soc UVD Indicator Type (Load 1): Soc ON Hours After Dusk (Load 2): Soc Viphtlight / Low Battery Settings Viphtlight / Low Battery Settings UVD Indicator Type (Load 1): Soc Viphtlight / Low Battery Settings Viphtlight / Low Battery Settings Viphtlight / Low Battery Settings Viphtlight / Low Battery Settings Solve Data Viphtlight / Low Battery Settings Nightlight / Low Battery Settings No Nightlight "ON" Hours After Dusk (Load 2): No Nightlight "ON" Hours After Dusk (Load 2): No Nightlight "ON" Hours Before Dawn (Load 2): No Nightlight UVD Load 2 Offset 1 LVD: Base + Offset (V): Day/Night Threshold: Day/Night Threshold: 6.0 Dimming Percentage: 100.0 Dimming Base Level Value: 100.0 Battery Type: Gel Goud Concoler <th>Interface</th> <th></th> <th></th> <th>phocos</th>	Interface			phocos
Man Meru Nightlight / Low Battery Settings Settings Detalogger and Staus Nightlight Mode (Load 1): 0 ON Hours After Dusk (Load 1): 0 ON Hours After Dusk (Load 1): 0 ON Hours After Dusk (Load 1): 0 UVD Indicator Type (Load 1): 50C UVD Indicator Type (Load 2): SoC Nightlight Mode (Load 1): 0 UVD Indicator Type (Load 2): No Nightlight "ON" Hours After Dusk (Load 2): 0 "ON" Hours After Dusk (Load 2): 4 UVD Indicator Type (Load 2): 50C UVD Indicator Type (Load 2): 0 UVD Indicator Type (Load 2): 4 UVD Indicator Type (Load 2): 6Gel UVD Indicator Type (Load 2): 6Gel UVD Indicator Type (Load 2): 4 UVD Indicator Type (Load 2): 6Gel UVD Indicator Type (Load 2): 6Gel UVD Indicator Type (Load 2): 100.0 UVD Indicator Type (Load 2):				
Settings Datalogger and Status ON Hours After Dusk (Load 1): 0 Ub Indicator Type (Load 1): 0 UD Indicator Type (Load 1): 0 UD Ioad 1 Offset: 4 UD Ioad 1 Offset: 4 VD Ioas After Dusk (Load 2): 0 "ON" Hours After Dusk (Load 2): 0 UD Iodicator Type (Load 2): 0 LVD Ioda 2 Offset 4 UD: Dad 2 Offset (V): Data Day/Night Threshold: 5.0 Battery Type: 6el Dimming Percentage: 15.496 Emergency High-Voltage: 14.408 </th <th>Main Menu</th> <th>Nightlight / Low Battery Settings</th> <th></th> <th></th>	Main Menu	Nightlight / Low Battery Settings		
ON Hours After Dusk (Load 1): 0 v image: Control of Set (V): Nightight / Low Battery Settings LVD Indicator Type (Load 1): 50C v image: Control of Set (V): Save Data No Nightlight Mode (Load 2): No Nightlight v image: Control of Set (V): Save Data No Nightlight Mode (Load 2): No Nightlight v image: Control of Set (V): No Nightlight Mode (Load 2): No Nightlight v image: Control of Set (V): ''ON" Hours After Dusk (Load 2): No Nightlight v image: Control of Set (V): ''ON" Hours After Dusk (Load 2): SoC v image: Control of Set (V): ''ON" Hours Before Dawn (Load 2): SoC v image: Control of Set (V): ''D' Dad 2 Offset (V): Day/Night Threshold: 5.0 i <t< td=""><td>Settings 💿 Datalogger and Status</td><td>Nightlight Mode (Load 1):</td><td>No Nightlight</td><td>~</td></t<>	Settings 💿 Datalogger and Status	Nightlight Mode (Load 1):	No Nightlight	~
Hundse ON Hours Before Dawn (Load 1): 0 0 0 Nightlight / Low Battery Settings LVD Indicator Type (Load 1): SoC 0 LVD Ioda 1 Offset 4 0 0 LVD Ioda 1 Offset 4 0 0 Nightlight Mode (Load 2): No Nightlight 0 0 "ON" Hours Before Dawn (Load 2): 0 0 0 "ON" Hours Before Dawn (Load 2): 0 0 0 "ON" Hours Before Dawn (Load 2): 0 0 0 "ON" Hours Before Dawn (Load 2): 0 0 0 "ON" Hours Before Dawn (Load 2): 0 0 0 "ON" Hours Before Dawn (Load 2): 0 0 0 "UD Iodicator Type (Load 2): 0 0 0 Day Night Threshold: 6.0 / 16.0 0 Battery Charge Regime Settings 100.0 0 0 Dimming Base Level Value: 100.0 0 0 Battery Charge Regime Settings 15,496 0 0 Equalize Voltage: 14,408 0 0 0 <td></td> <td>ON Hours After Dusk (Load 1):</td> <td>0</td> <td>~ [</td>		ON Hours After Dusk (Load 1):	0	~ [
Nyhtight / Low Battery Settings LVD Indicator Type (Load 1): SOC U Battery Charge Regime Settings LVD Ioad 1 Offset 4 V Save Data Nightlight Mode (Load 2): No Nightlight V Nightlight Mode (Load 2): No Nightlight V Ioad "ON" Hours After Dusk (Load 2): 0 V Ioad "ON" Hours After Dusk (Load 2): 0 V Ioad "ON" Hours After Dusk (Load 2): 0 V Ioad UVD Ioad 2 Offset 4 V Ioad LVD: Base + Offset (V): SoC V Ioad Day/Night Threshold: 8,0 / 16,0 V Battery Type: Gel V Ioo.0 V Dimming Base Level Value: 100.0 V Ioo.0 V Battery Charge Regime Settings Emergency High-Voltage: 14,408 V Ioo.0 Equalize Voltage: 14,408 V Iood Iood Iood Iood Battery Charge Soc: 13,992 Iood Iood Iood Iood Iood Iood Io	ttings Expert Mode	ON Hours Before Dawn (Load 1):	0	× .
Battery Charge Regime Settings LVD load 1 Offset: 4 ✓ Save Data Nightlight Mode (Load 2): No Nightlight ✓ "ON" Hours Before Dawn (Load 2): 0 ✓ ✓ "ON" Hours Before Dawn (Load 2): 0 ✓ ✓ "ON" Hours Before Dawn (Load 2): 0 ✓ ✓ UVD Indicator Type (Load 2): LVD Indicator Type (Load 2): ✓ ✓ UVD Load 2 Offset 4 ✓ ✓ LVD Base + Offset (V): Day/Night Threshold: 8.0 / 16.0 ✓ Day/Night Threshold: 8.0 / 16.0 ✓ ✓ Dimming Percentage: 50,0 ✓ ✓ ✓ Dimming Base Level Value: 100.0 ✓ ✓ ✓ Battery Charge Regime Settings Emergency High-Voltage: 14,408 ✓ ✓ Equalize Voltage: 14,408 ✓ ✓ ✓ ✓ Boost Voltage: 14,408 ✓ ✓ ✓ ✓ Hourinnum Charge Voltage: 13,992 ✓ ✓ ✓ ✓	Nightlight / Low Battery Settings	LVD Indicator Type (Load 1):	SOC	× 1
Battery Unarge Regime Settings Save Data Nightlight Mode (Load 2): "ON" Hours After Dusk (Load 2): UVD Indicator Type (Load 2): LVD Indicator Type (Load 2): LVD Indicator Type (Load 2): LVD Ease + Offset (V): Day/Night Threshold: 8.0 / 16.0 Battery Type: Dimming Percentage: 50.0 Dimming Percentage: 50.0 Dimming Base Level Value: 100.0 Battery Charge Regime Settings Emergency High-Voltage: 14,408 H4408 Equalize Voltage: 14,408 Hoininum Charge Voltage: 13,992 Load Reconnect Voltage: 13,992 Load Reconnect Voltage: 10,300 Emergency Low-Voltage: 10,472 Base Voltage SOC: 12,680 Maximum Step for SOC: 16 Yes Bastery Generos Controler 16	Rettery Charge Benime Settings	LVD load 1 Offset	4	\sim
Save Data Nightlight Mode (Load 2): No Nightlight "ON" Hours After Dusk (Load 2): 0 "ON" Hours After Dusk (Load 2): 0 "ON" Hours Before Dawn (Load 2): 0 UVD Indicator Type (Load 2): SoC LVD Load 2 Offset 4 Day/Night Threshold: 8.0 / 16.0 Battery Type: Gel Dimming Percentage: 50.0 Dimming Base Level Value: 100.0 Battery Charge Regime Settings Battery Charge Regime Settings: 14.408 Boost Voltage: 13.992 </td <td>Battery charge Regime Settings</td> <td>LVD: Base + Offset (V):</td> <td></td> <td></td>	Battery charge Regime Settings	LVD: Base + Offset (V):		
Ingention of the construction of th	Save Data	Nightlight Mode (Load 2):	No Nightlight	~
"ON" Hours Before Dawn (Load 2): 0 ·	Save Sale	"ON" Hours After Dusk (Load 2):	Constant Contract and Annual Annua	~
INPORT Productor Type (Load 2): SOC Import Settings INPORT Settings From Controller SoC Import Settings Send Settings Soc Import Settings Soc Import Settings Import Settings From Controller Soc Import Settings Import Settings Soc Import Settings Import Settings Import Settings Soc Import Settings Import Settings Import Settings From Controller Import Settings Import Settings Send Settings Send Settings Import Settings Import Settings		"ON" Hours Before Dawn (Load 2):	0	~
IVD Load 20 Offset: 4 LVD Load 20 Offset: 4 LVD: Base + Offset (V): 0 Day/Night Threshold: 8,0 / 16,0 Battery Type: Gel Dimming Percentage: 50,0 Dimming Base Level Value: 100,0 Battery Charge Regime Settings Emergency High-Voltage: 15,496 Maximum Charge Voltage: 14,408 Boost Voltage: 14,408 Minimum Boost Voltage: 13,992 Inport Settings from Controller Base Voltage: 10,472 Send Settings Base Voltage SOC: 12,680		LVD Indicator Type (Load 2):	SOC	~
LVD: Base + Offset (V): Day/Night Threshold: 8,0 / 16,0 ··· Battery Type: Gel ···· Dimming Percentage: 50,0 ··· Dimming Base Level Value: 100,0 ··· Battery Charge Regime Settings Emergency High-Voltage: Emergency High-Voltage: 14,408 ··· Boost Voltage: 14,408 ··· Boost Voltage: 14,408 ··· Hoiminum Boost Voltage: 13,992 ··· Minimum Charge Voltage: 13,992 ··· Minimum Charge Voltage: 13,000 ··· Emergency Low-Voltage: 10,472 ··· Base Voltage LVD: 10,984 ··· Base Voltage SOC: 12,680 ··· Temp. Compensation (mV/K): 0 ··· V Send Battery Charge Soft		LVD Load 2 Offset	4	~
Day/Night Threshold: 8,0 / 16,0 Battery Type: Gel <t< td=""><td></td><td>LVD: Base + Offset (V):</td><td></td><td></td></t<>		LVD: Base + Offset (V):		
Battery Type: Gel Dimming Percentage: 50,0 Dimming Base Level Value: 100,0 Battery Charge Regime Settings Emergency High-Voltage: 15,496 Maximum Charge Voltage: 14,408 Equalize Voltage: 14,408 Boost Voltage: 14,408 Hinimum Boost Voltage: 13,992 Kinimum Charge Voltage: 13,992 Load Reconnect Voltage: 13,000 Emergency Low-Voltage: 10,472 Base Voltage SOC: 12,680 Maximum Step for SOC: 16 V Send Battery Charge SoC: 12,680		Day/Night Threshold:	8,0 / 16,0	~
Dimming Percentage: 50,0 Dimming Base Level Value: 100,0 Battery Charge Regime Settings Emergency High-Voltage: 15,496 Maximum Charge Voltage: 14,408 Equalize Voltage: 14,408 Boost Voltage: 14,408 Boost Voltage: 13,992 Minimum Charge Voltage: 13,992 Load Reconnect Voltage: 10,472 Base Voltage SOC: 12,680 Maximum Step for SOC: 16 Temp. Compensation (mV/*K): 0		Battery Type:	Gel	~
Dimming Base Level Value: 100,0 ✓ Dimming Base Level Value: 100,0 ✓ Battery Charge Regime Settings ✓ Emergency High-Voltage: 15,496 ✓ Maximum Charge Voltage: 14,408 ✓ Equalize Voltage: 14,408 ✓ Boost Voltage: 14,408 ✓ Minimum Boost Voltage: 13,992 ✓ Minimum Charge Voltage: 13,992 ✓ Minimum Charge Voltage: 13,000 ✓ Load Reconnect Voltage: 10,472 ✓ Base Voltage SOC: 12,680 ✓ Maximum Step for SOC: 16 ✓ Temp. Compensation (mV/*K): 0 ✓		Dimming Percentage:	50,0	~
Battery Charge Regime Settings Emergency High-Voltage: 15,496 Maximum Charge Voltage: 14,408 Equalize Voltage: 14,408 Boost Voltage: 14,408 Minimum Boost Voltage: 14,408 Float Voltage: 13,992 Minimum Charge Voltage: 13,992 Load Reconnect Voltage: 13,000 Emergency Low-Voltage: 10,472 Base Voltage SOC: 12,680 Maximum Step for SOC: 16 Temp. Compensation (mV/*K): 0		Dimming Base Level Value:	100,0	~
Emergency High-Voltage: 15,496 Maximum Charge Voltage: 14,408 Equalize Voltage: 14,408 Boost Voltage: 14,408 Minimum Boost Voltage: 14,408 Float Voltage: 13,992 Minimum Charge Voltage: 13,992 Load Reconnect Voltage: 13,000 Emergency Low-Voltage: 10,472 Base Voltage SOC: 12,680 Maximum Step for SOC: 16 Vertice Settings Compensation (mV/'K): 0		Battery Charge Regime Settings		
Maximum Charge Voltage: 14,408 Equalize Voltage: 14,408 Boost Voltage: 14,408 Minimum Boost Voltage: 14,408 Float Voltage: 14,408 Minimum Charge Voltage: 13,992 Import Settings from Controller Emergency Low-Voltage: 13,000 Base Voltage LVD: 10,984 Base Voltage SOC: 12,680 Temp. Compensation (mV/*K): 0		Emergency High-Voltage:	15,496	~
Equalize Voltage: 14,408 Boost Voltage: 14,408 Minimum Boost Voltage: 14,408 Float Voltage: 13,992 Minimum Charge Voltage: 13,992 Load Reconnect Voltage: 13,000 Emergency Low-Voltage: 10,472 Base Voltage SOC: 12,680 Maximum Step for SOC: 16 Temp. Compensation (mV/*K): 0		Maximum Charge Voltage:	14,408	~
Boost Voltage: 14,408 Minimum Boost Voltage: 14,408 Float Voltage: 13,992 Minimum Charge Voltage: 13,992 Load Reconnect Voltage: 13,000 Emergency Low-Voltage: 10,472 Base Voltage LVD: 10,984 Base Voltage SOC: 12,680 Temp. Compensation (mV/*K): 0		Equalize Voltage:	14,408	~
Minimum Boost Voltage: 14,408 Float Voltage: 13,992 Minimum Charge Voltage: 13,992 Minimum Charge Voltage: 13,000 Load Reconnect Voltage: 10,472 Base Voltage LVD: 10,984 Base Voltage SOC: 12,680 Maximum Step for SOC: 16 Temp. Compensation (mV/*K): 0		Boost Voltage:	14,408	~
Float Voltage: 13,992 Minimum Charge Voltage: 13,992 Load Reconnect Voltage: 13,000 Emergency Low-Voltage: 10,472 Base Voltage LVD: 10,984 Maximum Step for SOC: 16 Temp. Compensation (mV/*K): 0		Minimum Boost Voltage:	14,408	~
Minimum Charge Voltage: 13,992 Load Reconnect Voltage: 13,000 Emergency Low-Voltage: 10,472 Base Voltage LVD: 10,984 Base Voltage SOC: 12,680 Maximum Step for SOC: 16 Temp. Compensation (mV/*K): 0		Float Voltage:	13,992	~
Import Settings from Controller Load Reconnect Voltage: 13,000 V Emergency Low-Voltage: 10,472 V Base Voltage LVD: 10,984 V Base Voltage SOC: 12,680 V Maximum Step for SOC: 16 V V Send Battery Compensation (mV/*K): 0 V		Minimum Charge Voltage:	13,992	~
Import Settings from Controller Emergency Low-Voltage: 10,472 V Base Voltage LVD: 10,984 V Base Voltage SOC: 12,680 V Maximum Step for SOC: 16 V Temp. Compensation (mV/*K): 0 V	~~~~~	Load Reconnect Voltage:	13,000	~
Send Settings Base Voltage LVD: 10,984 Base Voltage SOC: 12,680 Maximum Step for SOC: 16 Temp. Compensation (mV/*K): 0	Import Settings from Controller	Emergency Low-Voltage:	10,472	~
Send Settings Base Voltage SOC: 12,680 ~ Maximum Step for SOC: 16 ~ Temp. Compensation (mV/*K): 0 ~		Base Voltage LVD:	10,984	~
Maximum Step for SOC: 16 ✓ Temp. Compensation (mV/*K): 0 ✓	Send Settings	Base Voltage SOC:	12,680	~
Temp. Compensation (mV/*K): 0 Sector		Maximum Step for SOC:	16	~
Send Battery Charge Daties Cating		Temp. Compensation (mV/°K):	0	~
		Send Battery Charge Baging Setting		
	munication			

Figure 5.3: Select a Button to Utilize a Pre-programmed Battery Charge Profile

5.5 Saving Settings Files

To save settings files, either read the controller settings or program them. Select the "Save Data" radio button. Select the "Save CISCOM Data .cis" button. Use the file explorer to name and save the settings file.

Sciscom 3.13	
File Interface	
Main Menu	
O Settings O Datalogger and Status	
CSettings Expert Mode	Save File
Nightlight / Low Battery Settings	Save CISCOM Data .cis
Battery Charge Regime Settings	
O Save Data	

Figure 5.4: Select the "Save Data" radio button and "Save CISCOM Data" button to save settings files



6.0 Troubleshooting and Workarounds

6.1 Error Codes

Error Code	Error Code Dialogue Box Warning	Troubleshooting Steps
1	Communication failed. Unable to open the port.	Select a COM Port from the Interface menu. If none are available, select the refresh option. If none are available, install the MXI-IR drivers. See MXI-IR Driver Installation Guide available at <u>www.phocos.com</u> .
2	Communication failed. No data received.	Ensure the charge controller is powered on, there are no obstructions between IR transceivers, and the controller and MXI-IR are within 8m.
12	Communication failed. Wrong dataframe.	Remove any obstacles from between the IR transceiver of the MXI-IR and CIS family controller.

6.2 Workarounds

To save settings files when using non-expert mode, program a controller. Enter Expert Mode. Read the controller settings, and then save the settings file.

For easier load programming when only the battery charge regime Expert settings are required, use the graphical interface in non-expert mode. Program a controller. Enter Expert Mode. Read the controller settings. Adjust the battery charge regime settings, and either reprogram the controller or save the settings file.

7.0 Liability Exclusion

The manufacturer shall not be liable for damages, especially on the battery, caused by use other than as intended or as mentioned in this manual or if the recommendations of the battery manufacturer are neglected. The manufacturer shall not be liable if there has been service or repair carried out by any unauthorized person, unusual use, wrong installation, or bad system design.

Copyright ©2020 Phocos. All rights reserved. Subject to change without notice. Version: 20200511

Phocos AG Magirus-Deutz-Str. 12 89077 Ulm, Germany Phone +49 731 9380688-0 Fax +49 731 9380688-50 www.phocos.com info@phocos.com